




DIAGRAM PACKAGE for the *Kodak X-Omat* 180 LP and 180 LPS PROCESSORS



PLEASE NOTE The information contained herein is based on the experience and knowledge relating to the subject matter gained by Eastman Kodak Company prior to publication.

No patent license is granted by this information.

Eastman Kodak Company reserves the right to change this information without notice, and makes no warranty, express or implied, with respect to this information. Kodak shall not be liable for any loss or damage, including consequential or special damages, resulting from any use of this information, even if loss or damage is caused by Kodak's negligence or other fault.




 This equipment includes parts and assemblies sensitive to damage from electrostatic discharge. Use caution to prevent damage during all service procedures.

Table of Contents

Description	Page
Diagrams	3
AC Circuit Diagram	3
DC Circuit Diagram	4
External Wiring Diagram	5
External Box Wiring Diagram	6
Publication History	7





Section 2: Publication History

Print Date	Pub. No.	ECO No.	Affected Pages	File Name	Notes
July 1995	1C7841	2619-099	All pages	di3198_1_099.doc	First printing
Feb 1996	1C7841	2619-124	All pages	di3198_1_124.doc	Updated the diagrams to include serial number breaks.
Sep 1997	1C7841		All pages	di319800.doc	First CD-ROM printing. Content is identical to Feb 1996 version; formatting may vary from print version.

Kodak and *X-Omat* are trademarks.

